

MODEL name	MODEL #		CLIP	CHARGER	BATTERY	MUZZLE
			<i>loader for BB's</i>	<i>plug in wall</i>		<b>COMPENSATOR</b>
<b>Walther P22</b>	U-SAP22	<b>OBSOLETE</b>	P22-001			
<b>Walther P99</b>	U-SAP99	<b>OBSOLETE</b>	P99-001			
<b>Pulse P70</b>	SAPP70B		P70-001		AAA	
	SAPP70CB		P70C-001		AAA	
<b>Pulse P50</b>	SAPP50	<b>OBSOLETE</b>	P50-001			
<b>Pulse P72</b>	SAPP72		PP72-001	PP72-006	PP72-005	PP72-002
<b>Pulse M70</b>	SAPM70		PM70-001		AA	
<b>Pulse M72</b>	SAPM72	<b>NOT</b>	<b>GOING</b>	<b>FORWARD</b>		
<b>Pulse R70</b>	SAPR70	<b>OBSOLETE</b>	PR70-001	PR7074-006	PR70-005	
	SAPR70C	<b>OBSOLETE</b>	PR70-001	PR7074-006	PR70C-005	
	SAPR70BXC	<b>OBSOLETE</b>	PR70-001	PR7074-006	PR70C-005	
<b>Pulse R72</b>	SAPR72		PR72C-001	PR72-006	PR72-005	
	SAPR72B		PR72-001	PR72-006	PR72-005	
<b>Pulse R71</b>	SAPR71		PR70-001 - Hopper not see thru	PR71-006	PR71-002	
	SAPR71C		PR70-001 - Hopper not see thru	PR71-006	PR71-002	
<b>Pulse R73</b>	SAPR73		PR73-001 - Hopper - see thru	PR73-006	PR73-002	
	SAPR73C		PR73-001 - Hopper - see thru	PR73-006	PR73-002	
<b>Pulse R74</b>	SAPR74B		PR74-001	PR7074-006	PR74-005	
	SAPR74CB		PR74-001	PR7074-006	PR74-005	
<b>Pulse R75</b>	SAPR75B		PR75-001 - Round top loader	PR75-006	PR75-005	
<b>Pulse R76</b>	SAPR76		PR76-001	PR76-006	PR76-005	
	SAPR76CB		PR76-001	PR76-006	PR76-005	
	SAPR76TB		PR76-001	PR76-006	PR76-005	
<b>Nightprowler</b>	SAPNSCA		PNSCA-001 - Hopper - see thru	PNS-006	PNS-005	
	SAPNSCB		PNSCB-001 - Hopper - see thru	PNS-006	PNS-005	
<b>Air Mag C11</b>	SAMC11CB		SAMC11-001 (PARTS)			
			(CAN ALSO USE PACK OF 2-ACCESSORY-CROSM2C11)			

	MODEL #		CLIP	CHARGER	BATTERY	MUZZLE/COMP
<b>Air Mag M50</b>	SAMM50	<b>OBSOLETE</b>	SAMM50-001			
	SAMM50C	<b>OBSOLETE</b>	SAMM50-001			
<b>Air Mag P52</b>	SAMP52		SAMC11-001			
	SAMP52CB		SAMC11-001			
<b>Stinger P30</b>	SASP30CB		P30-001			
	SASP30B	<b>OBSOLETE</b>	P30-001			
<b>Stinger P32</b>	SASP32	<b>OBSOLETE</b>	SP32-001			
	SASP32C		SP32C-001			
<b>Stinger P36</b>	SASP36CB		P36-001			
	SASP38KT	<b>OBSOLETE</b>	P38-001			
<b>Stinger P9</b>	SASP9BH		SASP9-001			
	SASP9BST	<b>OBSOLETE</b>	SASP9-001			
	SASP9BCH		SASP9-001			
	SASP9CAH		SASP9-001			
	SASSP9CCA		SASP9-001			
<b>Stinger P30</b>	SASP30TKT		P30-001			
	SASP30CBTKT		P30-001			
	SASP30DK		P30-001			
<b>Stinger P312</b>	SASP312KT		SP312-001			SP312-002
<b>Stinger R30</b>	SASR30	<b>OBSOLETE</b>	R30-001			
	SASR31	<b>NOT</b>	<b>GOING</b>	<b>FORWARD</b>		
	SASR31CB	<b>NOT</b>	<b>GOING</b>	<b>FORWARD</b>		
<b>Stinger R32</b>	SASR32	<b>OBSOLETE</b>	R32-001			
<b>Stinger R34</b>	SASR34		R34-001			
	SASR34C		R34C-001			
<b>Stinger R36</b>	SASR36		R36-001			
	SASR36C	<b>OBSOLETE</b>	R36C-001			
<b>Sniper R38</b>	SASR38	<b>OBSOLETE</b>	SR38-001			

	MODEL #		CLIP	CHARGER	BATTERY	MUZZLE/COMP
<b>Stinger S30</b>	SASS30	<b>OBSOLETE</b>	S30-001			
<b>Stinger S32</b>	SASS32P		S32P-001 (short black)			
	SASS32PA		S32PACAM-001 (long camo)			
<b>Stinger S34P</b>	SASS34P		SM334P - 3PK Shot gun shell			
	SASS34PCA		SM334P - 3PK Shot gun shell			
	SASS34PCA		SM334P - 3PK Shot gun shell			
<b>Air Mag S1008</b>	S1008KT	<b>OBSOLETE</b>	S1008KT-013			
<b>R Wingmaster</b>	RWMSA		RWMSA-001			
<b>Rem TAC 1</b>	RTAC1		RTAC1-001			
	RTAC1CB		RTAC1-001			
<b>B= black</b>	<b>CA= camo</b>	<b>K= kit</b>	<b>CB= clear &amp; black</b>	<b>C=clear</b>		